



Make 3 brackets, mount them around smoker body between the existing brackets. Drilling the mounting holes 4 3/8" below the upper bracket mounting screws (or 5 1/4" below the top rim of the smoker body) will center the rack between the existing brackets.